

→ To install the current transformers (CTs):



## NOTE

If installing a high-accuracy/RGM meter, make sure that the CTs chosen are appropriate for use with the meter.

- 1. Turn off AC power before clamping on current transformers.
- Install the CTs around the conductor to be measured. Splitcore CTs can be opened for installation around a conductor. A nylon cable tie may be secured around the CT to prevent accidental opening.
- Install the CTs with the arrows pointing to the grid for consumption or export measurement.